

# AMBIRAD SPARES LIST

## Warm Air Unit Heaters - SCA Series.

Part No	Description	SCA45	SCA75	SCA100	SCA125	SCA150	SCA200	SCA250	SCA300
SCE42	Ignition electrode	X	X	X	X	X	X	X	X
SCS43	Flame sensor	X	X	X	X	X	X	X	X
SCFC1	Fan control	X	X	X	X	X	X	X	X
SCLC3	Overheat stat c/w capillary LC3	X	X	X	X	X	X	X	X
SCLC1	Overheat limit control LC1	X	X	X	X	X	X	X	X
2088	Gas valve spark On/Off	X	X	X	X	X			
2089	Gas valve spark On/Off						X	X	X
2074	Auto ignition controller H/well S4560C	X	X	X	X	X	X	X	X
R134974	Flue venter motor 3kg					X	X	X	X
SCV11	Flue venter motor up to sn 004500137 2kg	X							
SCV13	Flue venter motor up to sn 004500137 2kg		X	X	X				
R135979	Venter wheel SCA up to sn 004500138	X	X	X	X				
R135980	Venter wheel SCA up to sn 004500138					X	X	X	X
STV01A	Venter wheel after sn 004500138		X	X	X	X	X	X	X
SCV01A	Venter wheel after sn 004500138	X							
STV01E	Venter wheel 6.31" diameter		X	X	X	X			
SCV28	Flue venter motor after sn 004500137 1kg	X							
STV01	Flue venter motor after sn 004500138 3kg		X	X	X	X	X	X	X
SCPS51	Pressure switch 80Pa up to sn 004500137	X							
SCPS52	Pressure switch 100Pa up to sn 004500137		X			X			
SCPS53	Pressure switch 163Pa up to sn 004500137						X	X	
SCPS54	Pressure switch 218Pa up to sn 004500137			X	X				X
SCPS130	Pressure switch 158Pa after sn 004500138		X	X	X	X	X	X	X
SCFM21	Supply fan motor 2kg	X							
SCFM037	Supply fan motor 9kg				X	X	X		
SCFM040	Supply fan motor 9kg							X	X
SCFIL1	SCA filter inline	X	X	X	X	X	X	X	X
SCFM015	Supply fan motor after SN 004500138 5kg		X	X	X				
SCFB30	Fan blade	X							
SCFB11	Fan blade			X					
SCFB13	Fan blade				X				
SCFB33	Fan blade					X	X		
SCFB35	Fan blade							X	X
SCFB10	Fan blade		X						

Note All Part Numbers beginning with R or S are suitable for Series 1  
 All Part Numbers beginning with 2 or 8 are suitable for Series 2