

AMBIRAD SPARES LIST

Warm Air Unit Heaters - UF-2 Series.

Part No	Description	UF50 - 75	UF100 - 125	UF165	UF200	UF250 - 400
2076-3	Nut & olive for pilot tube	X	X	X	X	X
R133636	Permanent pilot assembly inc. injector	X	X	X	X	X
R135365	Spark ignitor pilot assembly inc. injector	X	X	X	X	X
R173036	Piezo ignitor	X	X	X	X	X
R125835	Thermocouple	X	X	X	X	X
R123976	Fan control	X	X	X		
R123974	Fan control				X	X
R151789	Overheat stat c/w capillary up to 3/97	X	X			
R151790	Overheat stat c/w capillary up to 3/97			X	X	
R151791	Overheat stat c/w capillary up to 3/97					X
R57953	Auto reset limit control after 3/97	X	X		X	X
R151792	Auto reset limit control after 3/97			X		
2086	ECO connector P/Pilot only	X	X	X	X	X
2083	Gas valve P/Pilot On/Off	X	X	X	X	X
R133789	Supply fan motor 2kg	X				
R121277	Supply fan motor 5kg		X	X	X	
R121276	Supply fan motor 8kg					X

Note All Part Numbers beginning with R or S are suitable for Series 1

All Part Numbers beginning with 2 or 8 are suitable for Series 2